



A Touchstone Energy® Cooperative 

Phone: 817.444.3201 ★ tcectexas.com

DISTRIBUTED GENERATION

Procedures & Guidelines

Manual for our Member-Owners

April 2023

TABLE OF CONTENTS

GENERAL.....	3
I. DETERMINE THE CATEGORY OF DG FACILITY	4
1) Connection Level Category.....	4
2) Power Export Category.....	4
3) Size Category	4
II. MEMBER'S INITIAL REQUIREMENTS.....	5
1) Notification.....	5
2) Service Request.....	5
3) Submit a DG Plan.....	5
III. COOPERATIVE AND POWER SUPPLIER REVIEW PROCESS.....	6
IV. SALES TO AND PURCHASES FROM A DG INSTALLATION.....	7
1) For all DG where the Member desires to export power.....	7
2) For facilities ≤ 15 kW where the Member desires to export power.....	7
3) For facilities > 15 kW where the Member desires to export power.....	7-8
V. MEMBER'S RESPONSIBILITY PRIOR TO OPERATION.....	8
1) Line Extension and Modifications to Cooperative Facilities.....	9
2) Applicable Regulations	9
3) Liability Insurance	10
4) Contracts	10
5) Initial Interconnection.....	10
VI. REFUSAL TO INTERCONNECT SERVICE OR DISCONNECTION OF INTERCONNECTION SERVICE.....	11
VII. OPERATION OF PARALLEL FACILITY.....	11
1) Ownership of facilities	11
2) Self-Protection of DG Facilities	11
3) Quality of service	12
4) Safety disconnect.....	12
5) Access	13
6) Liability for Injury and Damages.....	13
7) Metering/Monitoring	14
8) Notice of Change in Installation	15
9) Testing and Record Keeping.....	15
10) Disconnection of Service.....	15
11) Compliance with Laws, Rules and Tariffs.....	16
12) Payment of Fees	16
13) Net Metering	16
14) Submission.....	16
15) Rejection of Applications	17

GENERAL

In order to receive service from Tri-County Electric Cooperative, Inc (Cooperative), a customer must join or become a Member of the Cooperative. Throughout this manual, customers will be referred to as “Members.” For more information about the cooperative membership application process, including any applicable membership fees or deposits, see the Cooperative to request new member information.

It is the intent of the Cooperative to allow Members to install Distributed Generation (DG), provided the Member’s DG facility does not adversely affect the Cooperative. The Member must conduct his/her own analysis to determine the economic benefit of DG operation.

A DG facility that is not connected to the Cooperative’s system in any way is known as “stand-alone” or “isolated” DG. The Member may operate a DG facility in stand-alone or isolated fashion as long as such DG facility does not adversely affect the Cooperative’s system. A DG facility connected in any way to the Cooperative’s system shall be considered as in “parallel.” For purposes of this Manual, a DG facility is considered operating in “parallel” anytime it is connected to the Cooperative’s system in any way, even if the Member does not intend to export power. All provisions of this Manual shall apply to parallel operation of DG facilities as so defined.

This Manual is not a complete description or listing of all laws, ordinances, rules and regulations, nor is this Manual intended to be an installation or safety manual. The Member requesting to interconnect a DG facility to the Cooperative’s system is responsible for and must follow, in addition to all provisions of this Manual, the Cooperative’s *Rules and Regulations and Tariffs for Electric Service*, the Cooperative’s *Line Extension Policy*, the *Policies and Procedures* of the Cooperative’s power supplier where applicable, the *Policies and Procedures* of the Cooperative’s transmission serviceprovider where applicable, the current *IEEE 1547 Standard Guide for Distributed Generation Interconnection*, other applicable IEEE standards, applicable ANSI standards, including ANSI C84.1 Range A and any other applicable governmental and regulatory laws, rules, ordinances or requirements. All legal, technical, financial, etc. requirements in the following sections of this Manual must be met prior to interconnection of the DG facility to the Cooperative’s system.

A Member may serve all load behind the meter at the location serving the DG facility but will not be allowed to serve multiple meters, multiple consuming facilities or multiple Members with a single DG facility or under a single DG application without prior approval by the cooperative.

DG facilities larger than 15kW will be considered by the Cooperative on a case-by-case basis and are subject to Board approval.

I. DETERMINE THE CATEGORY OF DISTRIBUTED GENERATION FACILITY

1) Connection Level Category

- a) Connected to the Cooperative's system
The Member requests and/or the Member's DG facility requires connection to the Cooperative's system. All provisions of this manual cover this category.

2) Power Export Category

- a) Parallel – no power export
The Member operates a DG facility connected in any way to the Cooperative system but with no intention to export power.
- b) Parallel – power generated to be both consumed and exported
The Member operates a DG facility connected in any way to the Cooperative's system designed primarily to serve the Member's own load but with the intention to export excess power.
- c) Parallel – power generated to be exported only
The Member operates a DG facility connected in any way to the Cooperative's system designed primarily with the intention to export power. Presently, TCEC is not accepting applications of this type.

3) Size Category

- a) Facilities 15 kW and smaller
Facilities ≤ 15 kW of connected generation will be placed in this size category and be given net metering up to a zero-energy charge per billing cycle.
- b) Facilities above 15 kW
Facilities > 15 kW connected generation will be placed in this size category and are subject to engineering review and Board approval. The cooperative may provide net metering up to a zero-energy charge per billing cycle at its discretion.
- c) Calculation of Total DG output in kW
The kW, for the purposes of the application, is calculated using the maximum continuous rating for the inverter at 240VAC. In addition, all inverters associated with storage will be required to be added to the total to be considered correct.

II. MEMBER'S INITIAL REQUIREMENTS

1) Notification

- a) The Member must meet all the Cooperative's membership and service requirements in addition to the requirements in the Manual.
- b) Anyone owning or operating a DG facility in parallel with the Cooperative's system must notify the Cooperative of the existence, location and category of the DG facility.

2) Service Request

- a) In advance of request for an interconnection, the Member must contact the Cooperative and complete the "Cooperative Agreement for Interconnection and Parallel Operation of Distributed Generation."
- b) All DG facilities, regardless of kW must be pre-certified distributed generation (as defined under Chapter 25 of the Substantive rules or as so determined by the Cooperative).
- c) A separate form must be submitted for each facility.

3) Submit a DG Plan

- a) As a part of the application, the Member shall submit a plan detailing the electrical design, interconnection requirements, size, and operational plans for the DG facility (the "DG plan"). Either at the time of submission or at any time during the review process, the Cooperative may require additional information or may require the DG plan or any portion of the application to be prepared by a Professional Engineer registered in the state of Texas.
- b) At a minimum, the DG plan must contain an Electrical one line drawing and a facility drawing that shows the building, meter, disconnect and the nearest roads as they physically relate.
- c) In the case of DG facilities (i) to be operated in parallel with the Cooperative's system, (ii) with no intention to export power to the Cooperative and (iii) that are of standard design and intended entirely as emergency or back-up power supply for the facility, the Cooperative may, at its sole discretion, waive the application fee.
- d) Prior to review of the application and DG plan by the Cooperative, the Member shall pay an application fee as indicated below. A separate fee must be submitted for each DG facility.

DG Size (Connected Load)	Application Fee	Additional Engineering Fee
1 kW to 50 kW	\$500	As Required

III. COOPERATIVE AND POWER SUPPLIER REVIEW PROCESS

1) Plan Review Process

- a) The Cooperative and its Power Supplier, if requested by the Cooperative, will review the application and accompanying documents, plans, specifications, and other information provided and will return an interconnection analysis to the Member within 60 days of receipt of final plans and specifications.
- b) Technical review will be consistent with guidelines established by the most recent *IEEE Standard 1547 Guide for Distributed Generation Interconnection*. The Member may be required by the Cooperative to provide proof that their DG Facilities have been tested and certified by applicable IEEE guidelines.
- c) If corrections or changes to the plans, specifications and other information are to be made by the Member, the 60-day period may be reinitialized when such changes or corrections are provided to the Cooperative. In addition, any changes to the site or project requiring new analysis by the Cooperative may require additional cost and a new DG plan. The cost will be determined by the Cooperative and shall be paid by the Member.
- d) The Member acknowledges and agrees that any review or acceptance of such plans, specifications and other information by the Cooperative and/or its Power Supplier shall not impose any liability on the Cooperative and/or its Power Supplier and does not guarantee the adequacy of the Member's equipment or DG facility to perform its intended function. The Cooperative and its Power Supplier disclaim any expertise or special knowledge relating to the design or performance of generating installations and does not warrant the efficiency, cost-effectiveness, safety, durability, or reliability of such DG installations.
- e) In the event it is necessary at the time of initial interconnection or at some future time for the Cooperative and/or its Power Supplier to modify electric delivery systems in order to serve the Member's DG facilities and/or purchase or continue to purchase the output of the Member's DG facilities, or because the quality of the power provided by the Member's DG adversely affects the Cooperative's and/or its Power Supplier's delivery system, the Member will be responsible to pay the Cooperative and/or its Power Supplier in advance for all costs of modifications required for the interconnection of the Member's DG facilities.
- f) All applications over 15 kW are subject to engineering review and may be denied by engineering if concerns for the safe and reliable operation of the Tri-County system exist. Further, any application over 15kW may also be denied by the Board based on other concerns arising from the proposed installation.
- g) All applications over 15kW may exceed the 60 day time frame based on the amount of time required by engineering for review and coordination with the Board.

IV. SALES TO AND PURCHASES FROM A DG FACILITY

1) For all DG where the Member desires to export power

- a) All DG facilities shall be billed under one of the Cooperative's existing rate tariffs.
- b) All exchanges of electric power and energy by the Cooperative to a Member shall be consistent with the applicable retail rate schedule established by the Cooperative as if there were no DG installation at the Member's premises, including any charges in the Cooperative's DG tariff rider.
- c) The Member shall pay all rates and charges so listed.
- d) The Cooperative shall not make any purchases that will cause the Cooperative to no longer be in compliance with any applicable contracts or all-power contract requirements with its power supplier(s).

2) For installations \leq 15 kW where the Member desires to export power:

- a) For power produced in excess of on-site requirements, the Member will be compensated by netting the Member's kWh generation against the Member's kWh consumption, referred to as "net metering." The Cooperative shall bill the Member for the excess energy supplied by the Cooperative over and above the energy supplied by the Member during each billing period according to the Cooperative's applicable retail rate schedule.
- b) When the energy supplied by the Member exceeds the energy supplied by the Cooperative during a billing period, the monthly charge and/or minimum bill of the retail rate schedule shall be billed by the Cooperative in addition to the monthly metering charge, and the excess energy shall be provided at no charge to the Cooperative.
- c) The Member shall sign an approved contract for interconnection service with the Cooperative.
- d) In addition to all other charges, the Cooperative may bill the Member for any additional facilities charges as determined by the Cooperative and appended to the Interconnection Agreement.

3) For installations $>$ 15 kW where the Member desires to export power:

- a) The type of metering to be used shall be specified at the sole discretion of the Cooperative. The metering shall provide data so the Cooperative can determine each billing period the energy supplied to the Member by the Cooperative and the energy supplied to the Cooperative by the Member.
- b) At the sole discretion of the Cooperative, an approved load profile meter may be required which can be remotely read by the Cooperative through an approved communications link. Otherwise, the meter shall be read monthly by Cooperative personnel and the Member shall be billed for the additional cost of reading the meter if applicable.
- c) In addition to all other charges, the Cooperative may add an additional monthly customer charge for Members with DG facilities to recover any additional billing,

- meter reading and/or customer service costs.
- d) The Member shall sign an approved Agreement for Interconnection of Distributed Generation with the Cooperative if required.
 - e) In addition to all other charges, the Cooperative may bill the Member for any additional facilities charges as determined by the Cooperative and appended to the Interconnection Agreement.
 - f) The Cooperative may, at its sole discretion, provide net metering in the fashion described previously.

V. MEMBER'S RESPONSIBILITY PRIOR TO OPERATION

1) Line Extension and Modifications to Cooperative Facilities

- a) As a part of the interconnection analysis performed by the Cooperative, the Member will be provided with an estimate of any line extension or other cost to be incurred in providing electric delivery service to the Member's DG facility.
- b) Notwithstanding the Cooperative's line extension policy, the Member shall pay in advance the full cost of the construction of any transmission, substation, distribution, transformation, metering, protective, or other facilities or equipment which, at the sole discretion of the Cooperative and/or its Power supplier, is required to serve the Member's DG facility.
- c) In the event it is necessary at the time of initial interconnection or at some future time for the Cooperative and/or its Power Supplier to modify electric delivery systems in order to serve the Member's DG facilities and/or purchase or continue to purchase the Member's output, or because the quality of the power provided by the Member's DG adversely affects the Cooperative and/or its Power Supplier's delivery system, the Member will reimburse the Cooperative and/or its Power Supplier for all costs of modifications required for the interconnection of the Member's DG facilities.
- d) In the event the Cooperative at any time in the future changes primary voltage of facilities serving the DG facility such that metering equipment, transformers and/or any other Member-owned equipment must be changed to continue receiving service at the new primary voltage level, the full cost of the change will be borne by the Member.
- e) In all cases, the Member shall pay the full cost of the installation of a visible load break disconnect switch by and to the sole specification of the Cooperative. The switch will be readily accessible to Cooperative personnel and of a type that can be secured in an open position by a Cooperative lock.

2) Applicable Regulations

The DG facility shall be installed and operated subject to and in accordance with the terms and conditions set forth in the Cooperative's rules, regulations, bylaws, rates and tariffs, as amended from time to time, and, if applicable, approved by the Cooperative's board of directors, which are incorporated herein by reference, and in compliance with all applicable federal, state and local laws, regulations, zoning codes, building codes, safety rules, environmental restrictions, ordinances and regulations, including without limitation, the most recent IEEE Standard 1547 Guide for Distributed Generation Interconnection, applicable ANSI standards, including ANSI C84.1 Range A, Electric Reliability Council of Texas (ERCOT) Independent System Operator (ISO) directives and ERCOT guidelines, and in accordance with industry standard prudent engineering practices.

3) Liability Insurance

a) Facilities 15 kW and smaller

Liability insurance is recommended in the amount of \$500,000.

b) Facilities larger than 15 kW

Liability insurance is recommended in the amount of \$1,000,000.

4) Contracts

a) Interconnection Contract

The Member will sign and deliver an Agreement for Interconnection to the Cooperative substantially in the form as shown in the COOPERATIVE AGREEMENT FOR INTERCONNECTION AND PARALLEL OPERATION OF DISTRIBUTED GENERATION included in this Manual.

b) Power Credit Contract

(1) \leq 15 kW: Net Metering: As outlined in the Cooperative's tariffs

(2) $>$ 15 kW: Determined based on engineering review and Board approval.

5) Initial Interconnection

a) The interconnection will be completed after the review process and execution of the necessary agreements/contracts. After completion of interconnection requirements and prior to generating, applicant must provide pictures of the installation for scheduling a final inspection of the facilities. If the inspection fails the first time, there will be an inspection fee of \$100 for each inspection thereafter. Upon satisfactory final inspection, the Cooperative will provide Permission to Operate notice to the Member or their agent.

b) The Cooperative's review process and final inspection is intended as a means to safeguard the Cooperative's facilities and personnel. The Member acknowledges and agrees that any review or acceptance of such plans, specifications and other information by the Cooperative and/or its Power Supplier shall not impose any liability on the Cooperative and/or its Power Supplier and does not guarantee the adequacy of the Member's equipment or DG facility to perform its intended function. The Cooperative and its Power Supplier disclaims any expertise or special knowledge relating to the design or performance of generating installations and does not warrant the efficiency, cost-effectiveness, safety, durability, or reliability of such DG installations.

VI. REFUSAL TO INTERCONNECT SERVICE OR DISCONNECTION OF INTERCONNECTION SERVICE

The Cooperative may, at its sole discretion, prevent the interconnection or disconnect the interconnection of DG facilities due to reasons such as safety concerns, reliability issues, power quality issues, breach of interconnection contract or any other reasonable issue. Any disconnection may be without prior notice.

VII. OPERATION OF PARALLEL FACILITY

The purpose of this section is to outline the Cooperative's operational requirements for DG facilities operated in parallel with the Cooperative's system and is not intended to be a complete listing of all operational, regulatory, safety and other requirements.

1) Ownership of facilities

- a) The Member shall own and be solely responsible for all expense, installation, maintenance and operation of all facilities, including all power generating facilities, at and beyond the point of delivery as defined in the Cooperative's tariffs.
- b) At its sole discretion, the Cooperative may locate cooperative owned metering equipment and transformers past the point of delivery.

2) Self-Protection of DG Facilities

- a) The Member will furnish, install, operate and maintain in good order and repair all equipment necessary for the safe operation of DG facilities operated in parallel with the Cooperative system.
- b) The Member's equipment will have capability to both establish and maintain synchronism with the Cooperative system and to automatically disconnect and isolate the DG facility from the Cooperative system.
- c) The Member's DG facility will be designed, installed and maintained to be self-protected from normal and abnormal conditions on the Cooperative system including, but not limited to, over-voltage, under-voltage, overcurrent, frequency deviation, and faults. Self-protection will be compatible with all applicable Cooperative protection arrangements and operating policies.
- d) Additional protective devices and/or functions may be required by the Cooperative when, in the sole judgment of the Cooperative, the particular DG facility installation and/or the Cooperative system characteristics so warrant. At a Minimum, all DG installations intending to export must have a lockable disconnect located within six (6) feet of the Tri-County revenue meter.

3) Quality of service

- a) The Member's DG facility will generate power at the nominal voltage of the Cooperative's system at the Member's delivery point as defined by ANSI C84.1 Range A.
- b) Member's DG installation will generate power at a frequency within the tolerances as defined by IEEE 1547.
- c) Member's DG facility shall produce power at a minimum power factor of at least 97% or shall use power factor correction capacitors to ensure at least a 97% power factor.
- d) Member's DG facility shall be in accordance with the power quality limits specified in IEEE 519.
- e) The overall quality of the power provided by the Member's DG facility including, but not limited to, the effects of harmonic distortion, voltage regulation, voltage flicker, switching surges and power factor, will be such that the Cooperative system is not adversely affected in any manner.
- f) In the event that the adverse effects are caused in whole or in part by the Member's DG facility, the Member will correct the cause of such effects within 30 days and reimburse the Cooperative for any required correction or risk being disconnected from the Cooperative system.

4) Safety disconnect

- a) The Member shall install a visible load break disconnect switch at the Member's expense and to the Cooperative's specifications.
- b) The switch will be located so as to be readily accessible to Cooperative personnel in a location no more than six (6) feet from the revenue meter.
- c) The switch shall be a type that can be secured in an open position by a lock owned by the Cooperative. If the Cooperative has locked the disconnect switch open, the Member shall not operate or close the disconnect switch.
- d) The Cooperative shall have the right to lock the switch open when, in the judgment of the Cooperative:
 - (1) It is necessary to maintain safe electrical operating and/or maintenance conditions,
 - (2) The Member's DG adversely affects the Cooperative system, or
 - (3) There is a system emergency or other abnormal operating condition warranting disconnection.
- e) The Cooperative reserves the right to operate the disconnect switch for the protection of the Cooperative system even if it affects the Member's DG facility. In the event the Cooperative opens and/or closes the disconnect switch:
 - (1) The Cooperative shall not be responsible for energization or restoration of parallel operation of the DG facility.
 - (2) The Cooperative will make reasonable efforts to notify the Member.
- f) The Member will not bypass the disconnect switch at any time for any reason.
- g) Signage shall be placed by the Member at the Member's expense and located at

the disconnect indicating the purpose of the switch.

- h) Members with DG facilities as defined in this Manual which are solely for the purpose of emergency backup or peak shaving without intent to export power shall not operate their DG facilities at any time unless visibly disconnected from the Cooperative system. At its sole discretion, the Cooperative may require Member to install at his/her own expense an interlocking switch for the purpose of insuring the Member's facilities do not operate in parallel with the Cooperative's facilities.
- i) Should the Cooperative lose power serving the Member's DG facilities for any reason, Members with DG facilities shall not operate their DG facilities unless visibly disconnected from the Cooperative system.
- j) Any system with storage or designed to operate as stand-by power must have an automatic disconnect.

5) Access

- a) Persons authorized by the Cooperative will have the right to enter the Member's property for purposes of testing, operating the disconnect switch, reading or testing the metering equipment, maintaining right-of-way or other DG facility equipment and/or Cooperative service requirement. Such entry onto the Member's property may be without notice.
- b) If the Member erects or maintains locked gates or other barriers, the Member will furnish the Cooperative with convenient means to circumvent the barrier for full access for the above-mentioned reasons.

6) Liability for Injury and Damages

- (a) The Member assumes full responsibility for electric energy furnished at and past the point of interconnection and shall indemnify the Cooperative and/or its Power Supplier against and hold the Cooperative and/or its Power Supplier harmless from all claims for both injuries to persons, including death resulting therefrom, and damages to property occurring upon the premises owned or operated by Member arising from electric power and energy delivered by the Cooperative or in any way arising directly or indirectly from the Member's DG facility.

The Cooperative and/or its Power Supplier shall not be liable for either direct or consequential damages resulting from failures, interruptions, or voltage and waveform fluctuations occasioned by causes reasonably beyond the control of the Cooperative and/or its Power Supplier including, but not limited to, acts of God or public enemy, sabotage and/or vandalism, accidents, fire, explosion, labor troubles, strikes, order of any court or judge granted in any bona fide adverse legal proceeding or action, or any order of any commission, tribunal or governmental authority having jurisdiction. ALL PROVISIONS NOTWITHSTANDING, IN NO EVENT SHALL THE COOPERATIVE BE LIABLE TO THE MEMBER FOR ANY INTEREST, LOSS OF ANTICIPATED REVENUE, EARNINGS, PROFITS, OR INCREASED EXPENSE OF OPERATIONS, LOSS BY REASON OF SHUTDOWN OR NON-OPERATION OF MEMBER'S PREMISES OR FACILITIES FOR ANY INDIRECT, INCIDENTAL, OR CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES ARISING OUT OF

OR RELATED, IN WHOLE OR PART, TO THIS AGREEMENT. The Cooperative shall not be liable in any event for consequential damages.

- c) The Member is solely responsible for insuring his/her facility complies with all applicable regulations including, but not limited to, laws, regulations, ordinances, Cooperative and Cooperative Power Supplier tariffs, policies and directives, and ERCOT rules, policies and directives.

7) Metering/Monitoring

- a) The Cooperative shall specify, install and own all metering equipment.
- b) Facilities \leq 15 kW
The facility will be net metered by one of the following methods, at the sole discretion of the Cooperative.
 - (1) Installing a single meter which measures energy flow in both directions or
 - (2) Installing two meters, each measuring the flow of energy in a single direction and netting the energy consumption between the two meters to determine the net monthly flow of energy
- c) Facilities $>$ 15kW
 - (1) Power transfer at the point of interconnection will be measured by metering equipment as installed and specified at the sole discretion of the Cooperative.
 - (2) Net metering may be applied at the sole discretion of the Cooperative.
- d) The meter shall be read at a time or times of month determined at the Cooperative's sole discretion for acquiring metering data. The Member shall provide the Cooperative an approved communications link at the Member's cost for this purpose if so requested by the Cooperative. The type of communications link and metering equipment measuring purchase of power by the Cooperative shall be installed and specified at the sole discretion of the Cooperative.
- e) The Cooperative may, at its sole discretion, require the Member to pay the Cooperative in advance for metering and monitoring equipment and installation expense.
- f) Meter testing shall follow the Cooperative's standard policy on metering testing and accuracy.
- g) At its sole discretion, the Cooperative may meter the facility at primary or secondary level.

8) Notice of Change in Installation

- a) The Member will notify the Cooperative in writing thirty (30) days in advance of making any change affecting the characteristics, performance, or protection of the DG facility.
- b) If any modification undertaken by the Member will create or has created conditions which may be unsafe or adversely affect the Cooperative system, the Member shall immediately correct such conditions or be subject to immediate disconnection from the Cooperative system.
- c) Any change in the operating characteristics of the DG facility including, but not limited to, size of generator, total facility capacity, nature of facility, fuel source, site change, hours of operation, or type used, may require a new application process, including, but not limited to, application form, application fee, DG plan and DG plan review by the Cooperative.

9) Testing and Record Keeping

- a) The Member will test all aspects of the protection systems up to and including tripping of the generator and interconnection point at start-up and thereafter as required. Testing will verify all protective set points and relay/breaker trip timing and shall include procedures to functionally test all protective elements of the system. The Cooperative may witness the testing.
- b) The Member will maintain records of all maintenance activities, which the Cooperative may review at reasonable times.

10) Disconnection of Service

The Cooperative may, at its sole discretion, discontinue the interconnection of DG installations due to reasons such as safety concerns, reliability issues, power quality issues, breach of interconnection contract or any other reasonable issue.

11) Compliance with Laws, Rules and Tariffs

The DG installation owned and installed by the Member shall be installed and operated subject to and in accordance with the terms and conditions set forth in the Cooperative's rules, regulations, bylaws, rates and tariffs, as amended from time to time, and, if applicable, approved by the Cooperative's board of directors, which are incorporated herein by reference, and in compliance with all applicable federal, state and local laws, regulations, zoning codes, building codes, safety rules, environmental restrictions, ordinances and regulations, including without limitation, Electric Reliability Council of Texas (ERCOT) Independent System Operator (ISO) directives and ERCOT guidelines, and in accordance with industry standard prudent engineering practices.

12) Payment of fees

Due to security concerns, Tri-County will not take credit card payments from third parties. If a third party is responsible for payment of any fees, it must be made via check without exception, and mailed to 200 Bailey Ranch Road, Aledo, Texas 76008 and made payable to Tri-County Electric Cooperative. Members performing their own installation may elect to make payment via a credit or debit card in lieu of a check.

13) Net Metering

Tri-County provides a net metering to zero benefit to the members participating in the Distributed Generation program. Tri-County will exchange, one for one, all kWh provided to Tri-County against the kWh consumed from Tri-County up to a zero energy charge. Tri-County does not provide any further benefit from excess generation nor does Tri-County carry any overage forward.

14) Submission

All applications for distributed generation are to be submitted through the Tri-county web portal found at the following Address:

<https://submit.tcectexas.com/Forms/DistGenApp>

Any other submission method used may result in a longer approval time withno warranty on the time required to process the application.


There will be a \$100 charge added to the application fee after two failed submittal attempts (per address). It is recommended to review the manual and use the checklist provided at the end of the manual in order to submit what Tri-County Electric considers a complete application.

15) Rejection of Applications

Applications may be rejected for the following reasons:

- a) A notice from the installer.
- b) Failure to remit payment within 30 days of notice.
- c) Failure to respond to Tri-County requests for information within 30 days of the request.

Exhibit A



SCALE: 1"=20'-0"

Facility Layout